



■ 接続例



■ プリント基板タイプ



■ 標準E配列キーマトリクス

| CN Pin No. | USB/PS/2 | | | |
|------------|----------|------|-----|-----|
| | 1 | 3 | 5 | 7 |
| 2 | A | B | C | D |
| 4 | F9 | F10 | F11 | F12 |
| 6 | F5 | F6 | F7 | F8 |
| 8 | F1 | F2 | F3 | F4 |
| 10 | + | * | / | = |
| 12 | ESC | HOME | ← | → |
| 14 | 7 | 8 | 9 | ↑ |
| 16 | 4 | 5 | 6 | ↓ |
| 18 | 1 | 2 | 3 | BS |
| 20 | 0 | . | - | ↶ |

| CN Pin No. | RS-232C/PC-98 | | | |
|------------|---------------|------|----|----|
| | 1 | 3 | 5 | 7 |
| 2 | C | D | E | F |
| 4 | F9 | F10 | A | B |
| 6 | F5 | F6 | F7 | F8 |
| 8 | F1 | F2 | F3 | F4 |
| 10 | + | * | / | = |
| 12 | ESC | HELP | ← | → |
| 14 | 7 | 8 | 9 | ↑ |
| 16 | 4 | 5 | 6 | ↓ |
| 18 | 1 | 2 | 3 | BS |
| 20 | 0 | . | - | ↶ |